

How to Make Bath Bombs

1 cup baking soda	1 tsp. water
1/2 cup citric acid	2 tsp. essential oil
1/2 cup Epsom salts	3 tsp. oil (olive oil)
food coloring (any color you want)	
bath bomb mold	

Put all your dry ingredients in a bowl and mix them evenly with a whisk.

In a different container, add all your liquid ingredients and mix them together.

Put a small amount of your liquid mixture into your dry ingredients and mix it thoroughly. Mix until all the liquid has been absorbed by your dry ingredients. Continue adding small amounts of the liquid mixture until it is all used.

Now that you have mixed all the ingredients together, put it in the mold. Put a little more than what your mold can hold on both sides and press them together. You need to put extra in the mold so your mixture get pressed together making it solid.

Once it is pressed, gently tap it with a spoon to loosen your bath bomb.

Let dry for 1-2 days.

